

4116 Dr. Greaves Road  
Grandview, MO 64030  
Tel: (816) 767-0300  
Fax: (816) 763-0705

**Shuttlewagon, Inc.**

# Technical / Service

---

**Subject:** Steering Lock Override Adjustment

**Action:** Verify that the manual override (red Knurled knob) on hydraulic solenoid valve “SLS” is set to the released position. This valve is located on the main hydraulic manifold behind the front right hood side panel (nearest cab on the passenger side). Turn the manual override counterclockwise until it stops.

The steering may not lock as firmly in rail mode, if this manual override is not in the released position. Please verify this setting on '08 and newer models.

“SLS” SOLENOID  
VALVE MANUAL  
OVERRIDE (TURN  
COUNTERCOCK  
WISE)

